



INSTALLATION INSTRUCTIONS FOR WINDOW AIRBOX LID

Thank you for choosing to purchase a Carbonio product. Please take the time to fully read over these instructions before attempting to install the kit. This will greatly speed up the installation process and minimize any difficulties you may encounter.

Tools Required:

- Torx T-20 socket tip

Kit includes:

1 – Carbon fiber window airbox lid

LABOUR ESTIMATE GUIDE

30 Minutes

Step 1:

Using a T20 Torx socket tip remove the screws that hold the airbox lid in place and remove the airbox lid.



Step 2:

Install the window carbon fiber airbox lid using the screws from the OEM airbox removed in Step 1.

First fit the lid, then tighten all the screws so that they ALMOST seat, and lastly lightly tighten all the screws. It is not necessary to over tighten the screws.